

# Hydrogen - Analyser

Mobile Hydrogen - Analyser for Al - melt with user specific documentation



Type: HM 330 SN

CE

**Automatic operation, rapid and exact with reproducible results.**

Microprocessor controlled and user friendly  
Hydrogen-Tester based on the principle of „the first bubble“.

Measuring time < 30 sec.

Software for automatic recording and administration of the measured data.

Technical specifications:

Measuring range : 0,03 - 9,99 ccm / 100g

Resolution : 0,01

Dimensions : W550 x D600 x H1400 mm

Voltage : 115 V AC or 230 V AC

Integrated Industrial-PC with 15" TFT-Monitor  
and Keyboard (86 keys)

## IDECO

GESELLSCHAFT FÜR INDUSTRIELLE  
TECHNOLOGIE · ENTWICKLUNG · BERATUNG MBH

Im Fisserhook 3 - 5  
46395 Bocholt, Germany

+49 2871 - 6026

Fax +49 2871 - 6032

info@ideco-gmbh.de

www.ideco-gmbh.de



CONTROL Y MEDICIÓN  
LABORATORIO DE CALIBRACIÓN  
COMERCIALIZADORA

**Representante Exclusivo**

México: (-52) 55-5300-4517 Qro: (-52) 442-340-0250, 442-340-0251,  
Puebla: (-52) 222-219-9999, 222-418-1443, 222-228-1633

www.cmsmetrology.com.mx

www.controlymedicion.com.mx

