

VAC-TEST-SYSTEM

Method of producing low pressure samples for evaluation and analysis.



Type: **VM 613 DV**



Weight : 95 kg

Dimensions ca.: L960 x D600 x H954 mm

Voltage : 230V~/50Hz or 115V~/60Hz

Power Consumption : 580W

Automatic operation, rapid and exact with reproducible results.

VAC-TEST will determine the potential porosity content of your liquid metal.

The automatic evaluation of the DENSITY-INDEX from the samples gives precise and reproducible information about gas content, oxides and inclusions.

IDECO

GESELLSCHAFT FÜR INDUSTRIELLE
TECHNOLOGIE · ENTWICKLUNG · BERATUNG MBH

Im Fisserhook 3 - 5
46395 Bocholt, Germany

☎ +49 (0)2871 - 6026

info@ideco-gmbh.de

Fax +49 (0)2871 - 6032

www.ideco-gmbh.de

Representante Exclusivo

México: (-52) 55-5300-4517 Qro: (-52) 442-340-0250, 442-340-0251,
Puebla: (-52) 222-219-9999, 222-418-1443, 222-228-1633

www.cmsmetrology.com.mx

www.controlymedicion.com.mx



CONTROL Y MEDICIÓN
LABORATORIO DE CALIBRACIÓN
COMERCIALIZADORA

